





		<b>CERRADURAS GALCE</b>			
		<b>POSICIONES DE MONTAJE CORRECTAS</b>			
<b>SENTIDO APERTURA DE PUERTAS</b>		<b>MODELO</b>			
<b>1</b>		1400	1400/1	1400/2	1400/3
		1401/1	1401/2	1401/3	1402/1
		1402/2	1402/3	1403/1	1403/2
		1403/3	1410	1410/1	1410/2
		1410/3	1415	1415/1	1415/2
		1415/3	1416/1	1416/2	1416/3
		1417/1	1417/2	1417/3	1418/1
		1418/2	1418/3	1419/1	1419/2
		1419/3	1425/1	1425/2	1425/3
		<b>2</b>		1400	1400/1
1401/1	1401/2			1401/3	1402/1
1402/2	1402/3			1403/1	1403/2
1403/3	1410			1410/1	1410/2
1410/3	1415			1415/1	1415/2
1415/3	1416/1			1416/2	1416/3
1417/1	1417/2			1417/3	1418/1
1418/2	1418/3			1419/1	1419/2
1419/3	1425/1			1425/2	1425/3
<b>3</b>				1400	1400/1
		1401/1	1401/2	1401/3	1402/1
		1402/2	1402/3	1403/1	1403/2
		1403/3	1410	1410/1	1410/2
		1410/3	1415	1415/1	1415/2
		1415/3	1416/1	1416/2	1416/3
		1417/1	1417/2	1417/3	1418/1
		1418/2	1418/3	1419/1	1419/2
		1419/3	1425/1	1425/2	1425/3
		<b>4</b>		1400	1400/1
1401/1	1401/2			1401/3	1402/1
1402/2	1402/3			1403/1	1403/2
1403/3	1410			1410/1	1410/2
1410/3	1415			1415/1	1415/2
1415/3	1416/1			1416/2	1416/3
1417/1	1417/2			1417/3	1418/1
1418/2	1418/3			1419/1	1419/2
1419/3	1425/1			1425/2	1425/3

**OBSERVACIONES:**  
**El sentido de apertura será siempre hacia el mecanismo.**